


Art MASTER CD Autoprinter. Importing an image.



1. Open your Corel DRAW template.
2. From the menu bar select layout and from the drop down menu select Object manager. Site the object manager window in a suitable position. eg as shown.
3. Ensure the Mask and Template layers are locked and select layer 1. This is your work layer.
4. Click on the import button.
5. From the Import window select a graphics file to import and click import.
6. Your image appears in the template, but not necessarily in the correct place.
7. Drag the image nearer the correct position.
8. From the menu bar select Tools and from the drop down menu select Options.
9. In the options window set the units to mm and the nudge to 0.5mm. Click OK.
10. From the menu bar select Edit and from the drop down menu select Select All.
11. Use the arrow keys on your keyboard to nudge (adjust) the image within the template.
12. Save your image as- (eg Lloyds tower 1)
13. Print the image on a CD. (see printer set up)